



**Note:**  
In this situation where the Wanz window Bar is installed at Sill Locations the rear portion of the Nu-Therm Sill Flashing is to be removed and installed on top of the cavity batten allowing the Window bar to be fixed suitably.