



NOTE: FOR ADDITIONAL INFORMATION PERTAINING TO THIS DETAIL SEE INSTALLATION INSTRUCTIONS OF NU-THERM TECHNICAL MANUAL